Thanks so much for purchasing one of our Boom Blasters products!

Components and Installation Instructions

General Information: This infrared motion detector is very easy to get set up and requires no wiring.

Working Distance: 20-30 feet
Volume Control: 4 levels of volume

NOTE: Non-waterproof…for use indoors only.

Check out our video showing exactly how this wireless motion detector functions.

https://www.boomblasters.com/tutorials/

Programmable MP3 Motion Detector Components

Components Included:
1. MP3 Infrared Motion Detector (Batteries are not included)
2. USB Cable (to use for uploading sounds)
3. Wireless remote
4. Mounting hardware
5. Instructions Manual

How To Use

1. Install 3(AAA) batteries into your unit.

2. Plug the unit into your Windows computer using included USB cable.

2. Upload you own preferred MP3 sound file(s) from your computer onto the unit.

3. Mount the motion detector to your preferred location...turn the power on and test it.

ENJOY YOUR MOTION DETECTOR!!!

If you need help...we have VIDEO TUTORIALS right here...

https://www.boomblasters.com/tutorials/