

Boom Blasters "Sonic Boom Series Horn Kit"
<https://www.BoomBlasters.com>

Thanks for purchasing one of our Sonic Boom Series Horn Kits!



Components and Installation Instructions

NOTE: Our speaker horns are NOT waterproof, so be sure to mount it in a dry location. You can wrap your horn in a plastic bag after it is mounted under the hood or other location to help keep it dry and out of direct water contact. The sound will go through the thin plastic bag without any noticeable decrease in sound volume.

Check out our video explaining exactly how this horn kit functions and how to hook it up correctly.

<https://www.boomblasters.com/tutorials/>

TIP: Read through entire instructions carefully before beginning the installation process.

Sonic Series Kit Components

1. Amplifier unit w/Remote
2. 4"x4"x3" weather resistant horn(s). Some kits may have different horn variations and sizes.
3. 1 GIG USB thumb drive (to play and store your music)
4. Universal 12v power cord
5. Mini 3.5mm plug to 2 RCA male audio adapter
6. Instructions

Tools - Parts Needed (not provided):

1. Pliers
2. Tape for wiring connections
3. Additional wires may also be required for power, ground and speakers wires.
4. Wrench or suitable tool to connect power wires to battery (or other power source)
5. Bolts & nuts to mount it down
6. A few tie downs straps to safely secure the wiring
7. Windows Computer w/USB port (To upload your preferred sound files)

Installation should take around 30 to 45 minutes.

Boom Blasters "Sonic Boom Series Horn Kit"
<https://www.BoomBlasters.com>

Caution! Caution! Caution! Caution! Caution! Caution! Caution!

1. Do not install this unit while the vehicle is running!
2. When the unit is installed, ensure the wiring harness power lead wires are attached to a good known power source...to either the battery or a convenient fuse block. Red to Red (Positive), Black to Black (Negative).
3. Secure the unit properly and ensure the unit and all wiring are clear of any moving parts (i.e. fan belts, etc.) or items that can cause damage to the unit.

Sonic Boom Series Installation Instructions

NOTE: If you do not feel comfortable installing the Sonic Series Horn Kit, please seek qualified professional assistance.

Step 1: Battery Connection

- a. Install the Sonic Series Amplifier somewhere in the interior of your vehicle and away from any moving parts or areas that may cause damage to the Amp or the vehicle. **(The wiring harness red and black wires needs to be able to reach a good power and ground source.)**
- b. Connect the black wire from the wiring harness to the negative (-) side of the battery.
- c. Connect the red wire from the wiring harness to the positive (+) side of the battery.

Note:

- 1) **Ensure all connections are tightened properly!**
- 2) **Route wires neatly away from any moving parts to prevent damage.**

Step 2: Speaker Installation

Install the speaker(s) in a convenient location, but ensure the speaker wires will reach the unit.

Note: Route the speaker wires neatly away from any moving parts to prevent damage. The sound volume of the unit may vary depending on the placement of the speaker(s).

Remember our horns are NOT waterproof, so be sure to mount it in a dry location.

That's it! now go and hook up your Sonic Series horn kit.

If you are having troubles understanding the above procedures, then please refer to the tutorial videos that are right here for you to watch!

<https://www.boomblasters.com/tutorials/>

Remember our speaker horns are NOT waterproof, so be sure to mount it in a dry location and mount it away from any moving parts.

Enjoy your Boom Blasters "Sonic Series Horn Kit!"
