

Thanks so much for purchasing one of our Boom Blasters products!



Components and Installation Instructions

General Information: This wireless doorbell is very easy to get set up and requires no wiring.

Working Distance: 100- 150 meters

Volume Control: 4 levels of volume

Check out our video showing exactly how this wireless doorbell functions.

<https://www.boomblasters.com/tutorials/>

MP3 Wireless Doorbell Components

Components Included:

1. Wireless Plug-in Base Receiver
2. Push Button Transmitter (IP47 waterproof)
3. USB cable
4. Instructions Manual

How To Use

1. Plug the receiver unit into your Windows computer using included USB cable).
2. Upload you own preferred MP3 sound file from your computer onto the receiver base unit.
3. Install 3 AA batteries into your receiver unit and then mount your transmitter to your preferred location.

If both devices are successfully paired, the sounds from the doorbell will play correctly when the button on the transmitter is pushed...that's it...ENJOY YOUR DOORBELL!!!

If you need help...we have VIDEO TUTORIALS right here...

<https://www.boomblasters.com/tutorials/>
