

Thanks so much for purchasing one of our Boom Blasters products!



Components and Installation Instructions

General Information: This MP3 wireless doorbell is very easy to get set up and requires no wiring and also does NOT require batteries.

Working Distance: 100- 150 meters
Volume Control: 8 levels of volume

Check out our video showing exactly how this wireless doorbell functions.

<https://www.boomblasters.com/tutorials/>

MP3 Wireless Doorbell Components

Components Included:

1. Wireless Plug-in Base Receiver
2. Push Button Transmitter (IP47 waterproof)
3. Instructions Manual

How To Use

1. Plug the receiver unit into your Windows computer using an android compatible USB cable (USB CABLE IS INCLUDED).
2. Upload you own preferred MP3 sound file(s) from your computer onto the receiver base unit.
3. Plug your receiver unit into any household power plug and then mount your transmitter to your preferred location.

If both devices are successfully paired, the sounds from the doorbell will play correctly when the button on the transmitter is pushed...that's it...ENJOY YOUR DOORBELL!!!

<https://www.boomblasters.com/tutorials/>
